


TR	10	/	12	S
(1)	(2)	(3)	(4)	(5)



- (1)Triacs Type
- (2)Maximum average on-state Current A
- (3)/
- (4)Voltage code,codex100=Vrrm/Vdrm
- (5)case style:TO-220

