

TR	1	/	12	S
(1)	(2)	(3)	(4)	(5)

- (1)Triacs Type
- (2)Maximum average on-state Current A
- (3)/
- (4)Voltage code,codex100= V_{rrm}/V_{drm}
- (5)case style:TO-92

